


C260 User Manual




QUICK GUIDE


Preparing waste-holding tank



Preparing flush-water tank (only for C262-models)




Preparing Electric Ventilator (if applicable)




QUICK GUIDE


Emptying waste-holding tank



Emptying flush-water tank (only for C262-models)



Main parts



Standard

1 Cover • **2** Seat • **3** Swiveling toilet bowl • **4** Blade handle to open/close blade • **5** Control panel (position is different on C263-models) • **5a** Flush button • **5b** Waste-holding tank level indication (1 level or 3 levels; dependent on model) • **6** Pull handle • **7** Pour out spout • **8** Cap with measuring cup • **9** Automatic pressure release vent • **10** Vent button • **11** Sliding cover • **12** Blade opener • **13** Waste-holding tank mechanism • **14** Wheel • **15** Service door

Options

16 Waterfill door (only for C262-models) • **17** Console with flush-water tank (only for C262-models) • **18** Filter for Electric Ventilator • **19** Location Waste Pump-Out system

1 Introduction

This Thetford Cassette Toilet is a high quality product. It is user-friendly, meets high quality standards and gives you all the convenience of home.


Before operating and using this toilet we advise you to read the manual completely. Keep this manual in a safe place for future reference.

For the latest version of the manual please visit www.thetford.eu

Symbols used

- ✓ OK
- 👉 Tip
- 🔧 Special attention required
- ⚠ Caution (possible risk of injury or product damage)

2 Possible toilet options



Some toilets are fitted with extra options. To check which options are available, press the flush button on the control panel.

The following symbols can light up:

- 🚰 **Waste Pump-Out system**; transfers waste from the waste-holding tank into the vehicle's central waste tank
- 🔌 **Electric Blade**; electrically opens or closes the blade
- 🌀 **Electric Ventilator**; draws unpleasant odours away from the waste tank to the outside of the vehicle

You will find additional instructions to these options in the blue text boxes. Thoroughly read the applicable instructions.

3 Preparing for use

This Cassette Toilet has a waste-holding tank of 17.5L. A C262-model also has its own 8L flush-water tank. Before using your toilet, it is vital that you add toilet additives to these tanks. Check the correct dosage on the additive package. Then add ± 3 L of water to the waste-holding tank. Fill the flush-water tank of a C262-model to the top.

🌀 **Electric Ventilator (if applicable)**
Open the service door and remove the waste-holding tank. Then remove the filter housing cover and place the new filter into the filter housing. Replace the cover and return the waste-holding tank back to original position.

⚠ **Never add toilet additives directly via the blade as this could damage the lip seal of the waste-holding tank. Only fill the waste-holding tank via the pour out spout.**

⚠ **Never use force if you cannot get the waste-holding tank back into place easily. If blockage occurs, always check if the blade handle is in the closed position.**

See 'Quick Guide' diagrams 1-20 for visual reference. To depressurise the waste-holding tank, press the vent button before placing the tank back in its position.

Thetford offers a pleasantly scented toilet fluid for the flush-water tank (Aqua Rinse) and a variety of waste-holding tank products (Aqua Kem Blue, Aqua Kem Green, Aqua Kem Natural, Aqua Kem Sachets).




Aqua Rinse keeps the flush water fresh, ensures a smooth flush and leaves a protective layer. All products for the waste-holding tank suppress unpleasant smells, stimulate the breakdown of waste, reduce the formation of gas, protect moving parts and help to keep the waste-holding tank fresh and clean. For the differences between the distinguishing qualities of each waste-holding tank product please visit www.thetford.eu.

The range of available Toilet Care products may vary for each country.


4 Use of your toilet

Turning the bowl



You can turn this bowl to a desired position (max. $\pm 90^\circ$). Close the cover and use both hands to rotate the bowl as illustrated.

Opening the blade




The toilet can be used with the blade open or closed. To open the blade, slide the blade handle sideways as illustrated. Make sure you always close the blade completely after use.



Electric Blade (if applicable)

Press the flush button to activate the control panel. Then push the Electric Blade button. The blade will open or close electrically.

Flushing the toilet



Press the flush button once to activate the control panel. Then press the flush button for several seconds to flush the toilet.



Electric Ventilator (if applicable)

By activating the control panel, the Electric Ventilator starts automatically. The button will flash to indicate that this function is active. To stop the Electric Ventilator, press the button. Press the button again to re-start the ventilator. To optimise its function, activate the Electric Ventilator before use of your toilet.



Even without an own flush-water tank you can still use Aqua Rinse for a smooth and fresh lavender scented flush. Simply spray Aqua Rinse with a spray can even into the toilet bowl before use.



Ordinary toilet paper can cause clogging. Use Aqua Soft toilet paper instead. This toilet paper is super-soft, dissolves quickly, prevents clogging and makes it easier to empty the waste-holding tank.



Level indication

You can check whether your waste-holding tank has a 1-level or a 3-level indication. Make sure the tank is empty and place it back properly. Then activate the control panel. If no level indication light lights up, your toilet has a 1-level indication. It will only indicate a full tank. If a green level indication light immediately lights up, your toilet has a 3-level indication. It will indicate empty, half full and full.

5 Emptying the tank

Waste-holding tank

When the red light of the level indicator on the control panel lights up, you need to empty the waste-holding tank. Remove the tank via the service door. Then take it to an authorised waste disposal point. Empty the waste-holding tank via the pour out spout.



To empty the tank without splashing, press and hold the vent button with your thumb while the pour out spout is pointing downwards.



Waste Pump-Out system (if applicable)

By activating the control panel, this button automatically lights up. Press the button to empty the waste-holding tank into the vehicle's central waste tank. The button flashes while the waste is being pumped and stops flashing when all waste has been transferred. (± 1.5 L of waste is left). If the central waste tank is too full (only measured when this tank has a level indicator), the button flashes rapidly and no pump-out is possible until you have emptied the central waste tank.

See 'Quick Guide' diagrams 21-32 for visual reference. If you want to continue using your toilet after emptying, prepare the waste-holding tank again.



Our 'green' products Aqua Kem Green, Aqua Kem Natural and Aqua Rinse (test ISO 11734) are absolutely safe to empty into a septic tank or small biological systems on camping sites.



Please avoid to travel with a waste-holding tank that is more than $\frac{3}{4}$ full. This may cause leakage through the venting system.

Flush-water tank (only for C262-models)

The flush-water tank has a capacity of 8L. Only empty the flush-water tank completely if you don't expect to use your toilet for a long (winter) period. Place a sufficiently large bowl under the drain tube and catch the remaining water. Empty this bowl at an authorised waste disposal point.



See 'Quick Guide' diagrams 33-38 for visual reference.



To prevent water damage to your caravan or motor home, ensure that you don't travel with a full flush-water tank or with water in the bowl.

6 Cleaning

Just like your toilet at home, it is also important to clean this Cassette Toilet regularly. You will prevent limescale and ensure optimal hygiene. Clean the inside of the bowl with Toilet Bowl Cleaner and a soft brush and use Bathroom Cleaner for the outside of the toilet.




Never use household cleaners to clean your toilet. These may cause permanent damage to the seals and other toilet components.



Waste Pump-Out system (if applicable)

Fill the emptied waste-holding tank with water and place the tank back. Then activate the control panel. Press the Waste Pump-Out system button to pump the water through the system. Do this once every 3 weeks.

Remove seat & cover



To clean your toilet thoroughly, remove the seat and cover. First push the seat and cover together to the right, then lift them up.

7 Winter use

You can use your toilet as normal in cold weather as long as the toilet is situated in a heated location. If this is not the case, and there is a risk of frost, we advise not to use your toilet. Make sure you completely empty the waste-holding tank. For a C262-model also empty the flush-water tank.




Aqua Kem Sachets are particularly suitable for winter camping as the sachets are filled with powder. They completely dissolve in water, are easy to dose and economical in use.



8 Maintenance

To prolong the life span of your toilet, maintain your toilet regularly. Use Cassette Tank Cleaner 2 to 3 times a year on the waste-holding tank.



It safely removes stubborn limescale on the inside of the tank. When seals become dry, use Seal Lubricant to keep the seals soft and pliable. It has been



specially developed for mobile toilets and is absolutely safe to use.



Never use Vaseline or vegetable oil to lubricate the seals as these may cause leakage to your waste-holding tank.



Waste Pump-Out system (if applicable)

To ensure optimal functionality, maintain the waste-holding tank regularly. Fill the waste-holding tank with water and wash it. Then use Cassette Tank Cleaner. Do this every 6 weeks when on holiday.